

# 9160MC PARTS LIST

<u>#</u>	<u>Description</u>	<u>Stock #</u>	<u>#</u>	<u>Description</u>	<u>Stock #</u>
1.	Buttonhead Screw	9150-21	23.	Brush	TYX-3
2.	Buttonhead Screw	9160-20	24.	Bearings	9100-21
3.	Cap Screw	9100-17	25.	Belt Guard Bracket	9160-BRKT
4.	Cap Screw	9100-28	26.	Cutter Nut	9150-29
5.	Washer	9100-26	27.	Cutter	CW-23MC
6.	Washer	9160-21	28.	Copy Dog	9150-12
7.	Hex Nut	9160-22	29.	Adjusting Gib Screw	9100-27
8.	Motor Assembly	9160-MOTOR	30.	Snap Ring	9100-21A
9.	Key Gauge	9150-14	31.	Set Screw	9100-11
10.	Motor Pulley	9160-30	32.	Wing Nut	SNK-3
11.	Belt for 9160	9160-BELT	33.	Washer/Bearing Set	BBW-2
12.	Support Bracket	9160-TIE	34.	Top Jaw	TJAW-4
13.	Fiber Washer	9100-20	35.	Spring	9100-13
14.	Brush Nut	9100-25	36.	Bottom Jaw	BJAW-4
15.	Belt Guard	9160-GUARD	37.	Vise Stud	STUD-4
16.	Cutter Washers	9100-6	38.	Carriage Shaft	9150-15
17.	Shaft	9100-3	39.	Switch	9160-SW
18.	Cutter Guard	9100-16	40.	Carriage	CARR-9
19.	Washer	9100-17A	41.	Base Platform	9160-BASE
20.	Buttonhead Screw	9100-18A	42.	Buttonhead Screw	9150-18
21.	Cutter Shaft	9160-3	43.	Nut	9160-7A
22.	Machine Pulley	9100-19	44.	Cutter Washer	9100-6A
			45.	Base	9100-
			45.	Standard Tip Gauge	ST-4
			46.	Best/Short Tip Gauge	BT-4



# 9160MC

